

FLOAT & BOARD LEVEL INDICATOR



Registered No. 325327



Specifications:

GUIDED x Direct Indication

Service	:	Liquid with Sp.gr. 0.7
Measuring Range	:	7.5 mtrs. with 200 float 15 mtrs. with 350 float
Float	:	SS304 x 200mm SS304 x 350mm PP x 200mm
Calibrated Gauge Board	:	6" wide x Al. white powder coating with black graduation & numerals
Least Count	:	5 mm

Applications:

Liquid storage tanks having moderate turbulence and tank heights up to 15 meters.

	GUIDED x Follower Magnet Indication	UNGUIDED x Direct Indication
Service	: Liquid with Sp.gr. 0.7	Liquid with Sp.gr. 0.7
Measuring Range	: 3 mtrs with 200 float	3 mtrs. with 200 float
Float	: SS304 x 200mm PP x 200mm	SS304 x 200mm PP x 200 mm
Calibrated Gauge Board	: 4" wide x Al. white powder coating with black graduation & numerals	6" wide x Al. white powder coating with black graduation & numerals
Least Count	: 5 mm	5 mm
Applications:	Liquid storage tanks having corrosive fumes / vapors, as well as tanks having pressure maximum up to 1kg/cm ² & also for Nitrogen Purged Solvent Tanks.	Liquid storage tanks having moderate turbulence and tank heights up to 3 meters.



OASIS INSTRUMENTS CO.

Overseas Sales:

39 Ripon Street,
Kolkata – 700016
West Bengal, India
Telefax: +91-33-22293964

Domestic Sales:

2-2-103 to 108 Ranigunj
Ganesh Chamber, 2nd Floor
Secunderabad - 500 003
Andhra Pradesh, India
Telefax: +91-40-40025290

E-mail : oasis_instruments@yahoo.co.in, info@oasisinstruments.com
Url: www.oasisinstruments.com